

CLEANING ADVICE PULASTIC[®] SPORTS FLOORING



BUILDING TRUST

YOUR PULASTIC[®] SPORTS FLOOR IN TOP CONDITION BY CLEANING IT THOROUGHLY AND REGULARLY

You don't just decide to get a sports floor. After all, you want your investment to continue to pay off in the future too; preferably all your life. That is exactly what Sika thinks too, so it has developed an extensive service concept that guarantees that your Pulastic sports floor system meets all usage and safety requirements. Maintenance plays a crucial role in this. A large proportion of our customers already use Pulastic cleaning products and make use of our maintenance expertise.

Cleaning tips

Regular cleaning ensures that your Pulastic floor continues to retain its matte appearance and texture, which makes sure that the floor is safe to use and ensures optimum sporting performance. Sika's cleaning advice, including its Pulastic cleaning products, are of added benefit in this regard. It is easy to download the advice from the Pulastic website.

A clean start...

... is half the job. Before use, a newly delivered Pulastic floor should be lightly cleaned as a preventative measure using Pulastic Eco Clean.

The cleaning may be carried out just before the floor is first walked on – but at least five days after the sports floor coating is applied. This treatment must be carried out using a scrubber dryer. For further practical implementation, we refer you to the Pulastic instruction card for standard wet cleaning.



A dry clean...

...should be done every day using a dust-binding mop fitted with static mop cloths (without oily materials). This daily routine is important because dust and sand have an abrasive polishing effect and make surfaces smooth and shiny. Removing dust and sand has a very positive effect on the technical sports properties and sustainability of your Pulastic sports floor.

Removing stains...

...should be done every day in combination with the cleaning products described in the mark removal instruction card. This daily routine is important because marks will become attached to the floor. Certain marks may damage the Pulastic floor or be very difficult to remove as time goes on. Removing marks every day has a very positive effect on the sustainability of your Pulastic sports floor.

Standard wet cleaning...

...should be carried out at least once a week using a scrubber dryer fitted with red pads and the cleaning product Pulastic Eco Clean. It is important that the dissolved cleaning product is scrubbed into your floor and that the dirty water is drained away again immediately, so as to prevent dirt from drying into the floor. This is also referred to as the 'direct method'.

Pulastic Eco Clean must be used in the product–water ratio of 1:200. This means that 50 ml of product must be added to 10 litres of water.

If the result of the cleaning is unsatisfactory, it is recommended that you give the dissolved cleaning product the time to dissolve the dirt. The dissolved cleaning product is scrubbed into the floor but is not drained away immediately. Allow the applied solution to absorb for around 10 minutes, but don't allow it to dry into the floor! The dirt should then be removed by scrubbing. This is also referred to as the 'indirect method'.

We also refer you to the Pulastic instruction card, which contains pictograms, for standard everyday cleaning.

Intensive cleaning...

...must be carried out twice a year. A deep clean that removes soap residues, grease, dirt and bacteria can be carried out as soon as the floor is at least six months old. It is advisable to schedule this cleaning procedure from time to time, such as during the summer and Christmas holidays. The intense cleaning should be carried out using a scrubber dryer fitted with red pads and the cleaning product Pulastic Deep Clean.

The dissolved cleaning product is scrubbed into the floor but is not drained away immediately. Allow the applied solution to absorb for 5 to 10 minutes, but don't allow it to dry into the floor! The dirt should then be removed by scrubbing. This is also referred to as the 'indirect method'.

The floor should then be rinsed using the standard wet cleaning method with Pulastic Eco Clean, otherwise known as the 'direct method'. This action ensures that residue that has been left behind in the pores is removed. This step is inextricably linked to the intense cleaning procedure and should never be skipped!

SIKA NEDERLAND B.V.

Duurstedeweg 7 · 7418 CK Deventer · PO Box 420 · 7400 AK Deventer · The Netherlands Tel: +31 570 - 62 07 44 · www.pulastic.com



A SIKA BRAND

Pulastic Deep Clean must be used in the product-water ratio of 1:10. This means that 1 litre of product must be added to 10 litres of water.

We also refer you to the Pulastic instruction card, which contains pictograms, for intense cleaning.



Adapting your cleaning procedure...

...for safety and optimum sporting performance. This can be achieved by adapting your cleaning procedure to the level of dirt found on the floor as a result of the load exerted on your sports accommodation and specifically use of the Pulastic sports floor.

To understand this, an 'advice sheet for determining the cleaning procedure' is available. The standard advice given in this sheet will suffice in most situations when the floor is subjected to a normal load. You can of course always contact the sales department directly for tailor-made cleaning advice.

A few more tips

- Use of a good doormat prevents the spreading of dust and sand across the floor.
- The use of sports shoes with black soles increases the risk of lines that are difficult to remove and it is therefore highly recommended that you ban their use.
- Cold water is sufficient for the standard wet and intense clean. The use of lukewarm or warm water does not alter the effect of Pulastic cleaning products whatsoever.
- The scrubber dryers must be adjusted to low speed (no more than 150 revs per minute).
- Following Pulastic cleaning recommendations has a very positive effect on the longevity of your Pulastic sports floor.
- Detrimental effects caused by using cleaning products other than the original Pulastic products fall outside of Sika's responsibility and liability.
- Detrimental effects caused by using pads other than those prescribed fall outside of Sika's responsibility and liability.

Ordering Pulastic® cleaning products:

Scan the QR code to order your cleaning agents



PULASTIC[®] SPORTS FLOORING

A SIKA BRAND

SIKA NEDERLAND B.V.

Duurstedeweg 7 \cdot 7418 CK Deventer \cdot PO Box 420 \cdot 7400 AK Deventer \cdot The Netherlands Tel: 0570 - 62 07 44 \cdot www.sika.nl \cdot www.pulastic.com

ADVICE SHEET FOR DETERMINING CLEANING PROCEDURE

Information document for determining a balanced cleaning procedure for Pulastic sports floors

General information	 A high-quality sports floor deserves high-quality maintenance. That is why Sika Nederland B.V. provides an advice sheet for determining a balanced cleaning procedure. The effect of using and the load exerted on the Pulastic[®] sports floor is essential for choosing a cleaning regime. This advice sheet is intended as an information document. The use of resin (ball games) and/or magnesium (gymnastics) has direct consequences for choosing a cleaning a cleaning regime in the room in question. Please contact the Pulastic team for advice. For questions in the event of an alternative load or use of the Pulastic sports floor, please send an e-mail to: export@nl.sika.com or telephone: +31 570 620744. 				
Load factor	Low	Normal		High	
Cleaning procedure	Amended procedure Sports facilities with a low load factor, during the day and for 2-3 days per week	Standard Pulastic advice Sports facilities with an average load, during the day and possibly in the evening and for 4-5 days per week		Amended procedure Sports facilities with a high load factor, during the day and in the evening and for 6-7 days per week	
Removing marks	weekly	daily		daily	
Clearing dust	3 times a week	daily		2 times a day	
Wet cleaning with Pulastic Eco Clean	Once every two weeks using the 'indirect' method	At least once a week using the 'direct' method		At least three times a week using the 'direct' method	
			Or, at least twice a week using the 'indirect' method		
Periodic cleaning with Pulastic Deep Clean	1- 2 times a year	2 times a year		3 times a year	
Cleaning methods explained	'Direct method' 'Indirect method'				
	Step 1: Fill the scrubber dryer's water tank with the cleaning product solution, making sure that the ratio is correct.		Step 1: Fill the scrubber dryer's water tank with the maintenance product solution, making sure that the ratio is correct.		
	Step 2: Place the red pad (scourer) under the scrubber dryer.		Step 2: Place the red pad (scourer) under the scrubber dryer. For persistent stains, use the green/blue pad. Please note: This may affect the top layer.		
	<i>Step 3:</i> The solution should then be scrubbed onto the floor and drained away again immediately.		Step 3: The solution should then be scrubbed onto the floor.		
			Step 4: Allow the applied solution to absorb according to the directions on the maintenance product. PLEASE NOTE: Applied maintenance products must not be left behind or allowed to dry on the floor.		
			<i>Step 5:</i> Then scrul scrubber dryer.	b away the applied solution using the	
Legal notices	The information contained herein and any other advice are given in good faith based on Sika's current knowledge and experience of the products when properly stored, handled and applied under normal conditions in accordance with Sika's recommendations. The information only applies to the application(s) and product(s) expressly referred to herein and is based on laboratory tests which do not replace practical tests. In case of changes in the parameters of the application, such as changes in substrates etc., or in case of a different application, consult Sika's Technical Service prior to using Sika products. The information contained herein does not relieve the user of the products from testing them for the intended application and purpose. All orders are accepted subject to our current terms of sale and delivery. Users must always refer to the most recent issue of the local Product Data Sheet for the product concerned, copies of which will be supplied on request.				

SIKA NEDERLAND B.V.

Duurstedeweg 7 · 7418 CK Deventer · PO Box 420 · 7400 AK Deventer · The Netherlands Tel: 0570 - 62 07 44 · www.sika.nl · www.pulastic.com



INSTRUCTION SHEET STANDARD WET CLEANING

1. Dilution



Measure the quantity of the cleaning product **50 ml product per 10 L water (1:200)**

2. Attaching the pad



Attach the red pad underneath the scrubbing/suction machine.

3. Applying and sucking up fluids



Apply the fluid while scrubbing and let the machine suck it up immediately. Work at a normal walking pace.



Pulastic[®] Eco Clean

Standard cleaning agent after commissioning of the Pulastic[®] sports floor.

SIKA NEDERLAND B.V.

Duurstedeweg 7 · 7418 CK Deventer · PO Box 420 · 7400 AK Deventer · The Netherlands Tel: 0570 - 62 07 44 · www.sika.nl · www.pulastic.com



A SIKA BRAND


INSTRUCTION SHEET REGULAR CLEANING

1. Dilution



Measure the quantity of the cleaning product **1 L product per 10 L water (1:10)**

4. Exposure time



Important: Do not let the solution applied to the floor dry up





Attach the red pad underneath the scrubbing/suction machine.

5. Suction



Let the machine suck up the fluid while scrubbing. Work at a slow walking pace.

3. Applying fluid



Apply the fluid while scrubbing. Work at a normal walking pace.

6. Rinsing

Clean the Pulastic[®] sports floor again using Pulastic[®] Eco Clean as part of the regular cleaning cycle. See also the instruction sheet Standard wet cleaning.

Important: Do not skip this step.



Pulastic[®] Deep Clean

Cyclic cleaning agent (2x a year) **after the first 6 months** of use of Pulastic[®] sports floors. (steps 1-5).

Pulastic[®] Eco Clean

Cleaning agent for **rinsing** the Pulastic[®] sports floor. (step 6).



A SIKA BRAND

SIKA NEDERLAND B.V.

Duurstedeweg 7 · 7418 CK Deventer · PO Box 420 · 7400 AK Deventer · The Netherlands Tel: 0570 - 62 07 44 · www.sika.nl · www.pulastic.com

INSTRUCTION SHEET REMOVING STAINS

1. Spraying



Daily dusting and stain removal are part of the standard cleaning routine. Spray the Pulastic[®] maintenance product onto the stain and allow it to be absorbed. **Important:** Do **not** let the applied product dry up.

2. Scrubbing



Work on the stain with a scrubbing/circular movement. **Important:** Excessive scrubbing may damage the floor. Always use a mild pad.

3. Rubbing dry



Wipe the spot dry with a microfibre cloth. If necessary, repeat steps 1 to 3.



Pulastic[®] Eco Clean

Standard cleaning agent for the most common stains on Pulastic[®] sports floors.

Pulastic[®] Deep Clean

Powerfu

cleaning

agent

Powerful cleaning agent for more persistent stains on Pulastic[®] sports floors.

SIKA NEDERLAND B.V.

Duurstedeweg 7 · 7418 CK Deventer · PO Box 420 · 7400 AK Deventer · The Netherlands Tel: 0570 - 62 07 44 · www.sika.nl · www.pulastic.com



A SIKA BRAND

STAINS TABLE WHAT CLEANING AGENT TO USE FOR WHICH STAIN?

Type of contamination/stain	Product	Proportion	Note
Grease, oil, tar, marker	Pulastic® Eco Clean Pulastic® Deep Clean TASKI Speedball Original	10% 10% -	Manual Manual Manual *
Rubber streaks and smudges	Pulastic® Eco Clean Pulastic® Deep Clean	2% 10%	Manual Manual
Handball resin	TASKI Tapi Spotex 1	-	Manual *
Chewing gum	TASKI Tapi Gum	-	Manual *
Rust	Pulastic® Eco Clean Pulastic® Deep Clean TASKI Clonet	2% 10% 2%	Manual Manual Manual *
Confetti	Pulastic [®] Eco Clean	2%	Manual
Magnesium (local staining)	Pulastic [®] Eco Clean	2%	Manual
Magnesium (other than local staining)	Pulastic [®] Eco Clean	0.5%	Scrub/suction machine
Blood, vomit	Pulastic [®] Eco Clean	2%	Manual
Alcoholic beverages/ soft drinks	Pulastic [®] Eco Clean	2%	Manual
Food waste, fruit	Pulastic [®] Eco Clean	2%	Manual
Remainders of tape, stickers, glue	Pulastic® Eco Clean Pulastic® Deep Clean	10% 10%	Manual Manual

* For this product, please consult the manufacturer's instructions.



A SIKA BRAND

SIKA NEDERLAND B.V. Duurstedeweg 7 · 7418 CK Deventer · PO Box 420 · 7400 AK Deventer · The Netherlands Tel: 0570 - 62 07 44 · www.sika.nl · www.pulastic.com